



Use

Separation of grease coming from grey water or kitchen water.

Using a grease tank is required when the all-water tank is located more than 10 meters from the house.

Installation

Achieve a suitable bedding made of sand, place the unit and connect the pipes. Fill the device with clean water up before backfilling with sand.

Definition

The grease tank is a device retaining the waste water full of grease, these greases are stopped so that they do not clog the drain.

Maintenance

We recommend very frequent visits, at least 4 times per year. You must remove greases trapped on the surface of the grease tank.

The device must be drained periodically, must be washed and filled immediately with clean water up with a hose of diameter suitable to the volume of the device.

Reference	Dimensions in mm								Vol. in liters
	A	Ø B	Ø C	D	E	Ø F	G	H	
BG2/6066/200	661	637	1070	400	438	100	413	248	200
BG2/6066/500	790	830	1450	400	538	100	550	240	500
RH502	Screw-on extension shafts in polyethylene Ø 400 - height 250 mm								